



Nintendo 64 Top Cover Replacement

Written By: bbdiamond13



INTRODUCTION

This guide will assist in removing the top cover of the Nintendo 64.



TOOLS:

- [Gamebit 4.5mm](#) (1)
 - [Metal Spudger](#) (1)
-

Step 1 — Top Cover



- Remove the expansion pack cover by pushing in the tab and pulling out.

Step 2



- Lever the expansion pack out using the metal spudger.
- ⓘ A small spoon can be used in place of a spudger.

Step 3



- Remove the six screws on the bottom side indicated in the example with a gamebit head or screwdriver.

Step 4



- Remove the two front feet of the N64.

Step 5



- Rotate to top side up and lift off top cover.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 11:54:13 AM.